

EUROPROT +

**Centralized busbar differential and breaker failure
protection function**



Budapest, December 2015

Centralized busbar differential and breaker failure protection function

Protecta provides two different types for busbar protection. Both of them perform basically the well-known principle: the sum of the currents flowing into and out of the busbar results zero, if there are no internal faults. If the sum is not zero then there is an internal fault, and a fast trip command is generated. The scheme in both versions is the low impedance, biased differential scheme, the application of Kirchhoff's node law.

The difference between the two types is the structure of the differential protection system:

- Centralized version:
 - If the number of bays connected to the busbar is limited (there are not more bays than 6) the tasks related to the three-phase busbar differential protection function are performed within one device.
 - With increasing number of the bays the tasks are divided among three independent devices. Each of them is responsible for the differential protection of one phase (L1, L2 or L3) of the busbar. This version can be considered also as a centralized version.
- Decentralized version:
 - In this version other individual protective devices of the bays (e.g. distance protection, overcurrent protection, etc.) are involved in the busbar protection scheme. They are located in the substation according to the bay structure of the primary system. These devices perform the sampling of the currents and have access to all information needed for the busbar protection system. This information is sent by fiber optic link to the central unit. The calculation and decision is performed by the central unit, and the dedicated trip commands are sent back to the devices also via fiber optic links.

This short description contains the details of the centralized version; the decentralized version is described in a separate document.

The numerical protection integrates two independent protection functions:

- numerical differential protection,
- breaker failure protection.

The joint discussion of these functions is based on the fact that the breaker failure protection utilizes the same processed status information of the busbar protection to disconnect only the section of the busbar to which the faulty circuit breaker is connected. So the other zones can remain in continuous service.

The centralized numerical busbar differential protection system has two configuration possibilities:

- It can be realized in one device, processing all three phase currents of all bays if there are not more bays than 6, or
- It can consist of three identical devices processing the phase currents separately for the phases.

This description focuses on the three-phase version, but if needed, the difference as compared to the single phase version is also indicated.

The main features of the busbar differential protection function can be summarized as follows:

- The function is performed within one (or three) device(s), receiving analog currents and voltages and status signals from all bays of the busbar;
- Dynamic busbar replica, based on disconnecter status signals;
- High stability in case of external faults in spite of current transformer saturation;
- Short tripping time;
- Selectivity for internal fault, only the bays connected to the faulty busbar section are disconnected, all other bays remain in continuous operation;
- Easily to extend within the limitation of the hardware of three-phase or three single phase hardware versions;
- Easy adaptation of the function for different primary bus systems:
 - Single busbar,
 - Up to quadruple busbar,
 - Ring bus,
 - 1 ½ circuit breaker arrangement,
 - Bus couplers,
 - Bus sectionalizers with none, one or two current transformers,
 - Transfer bus;
- Individual numerical calculation and decision for all three phases;
- Stabilized differential current characteristics;
- The security and stability are increased with special software methods;
- Voltage breakdown condition;
- Check zone application;
- Saturated waveform compensation;
- Directionality check;
- Current transformer failure detection;
- Checking the disconnecter status signals;
- Included breaker failure protection.

The capabilities of the busbar differential protection function depend on the hardware configuration. This is a task of the factory process: based on the ordering, the required number of current inputs, binary inputs for disconnecter status signals and the required number of trip outputs are assembled into the device.

The applied software functions blocks are as follows:

1. "Busbar" function block: this performs the organization of the busbar protection system, and also the numerical calculations and decisions are performed in this module. Based on the disconnecter status information received from the bus sections "Measuring elements" are composed. A "Measuring element" processes all currents, which are flowing into or out of the interconnected bus sections. Accordingly the number of the processed "Measuring elements" can be the number of the individual bus sections, as a maximum; or there can be less "Measuring elements", if some bus sections are interconnected with each other. The "Measuring element" performs the algorithm for the interconnected busbar sections. The busbar protection function always contains one "Busbar" function block.
2. "Bus section" function blocks: the number of these blocks coincides with the number of the bus sections. Up to 12 sections can be included. The task of this function block is to process the status signals, and to send them to the "Busbar" block to form the "Measuring elements".

3. "Bay unit" function blocks: the number of these blocks coincides with the number of the bays in the substation. On the one hand, the task of these block is to receive and process all information from the primary devices of the bay:
- Currents (three phase currents or one phase current, depending of the selected option)
 - Voltages (three phase voltages or one phase voltage, depending of the selected option)
 - Status signals of the disconnectors: these signals are received with dual signals (disconnector open and disconnector closed). Up to 4 disconnectors can be configured to a physical bay.

On the other hand, this block passes the trip command to the circuit breaker of the bay.

This block also inputs the breaker failure signal from the bay protection units, and information related to the "stub" protection. On the other hand, the blocking input signal received by this bay unit disables the operation of the "Measuring element", to which this bay is dynamically assigned.

4. "Sectionalizer unit" function blocks: these blocks serve mapping the sectionalizer bays, the bays which interconnect bus sections with disconnectors. These blocks receive up to two disconnector status signals.

The algorithm continuously evaluates the status signals of the disconnectors and if there are changes in the status signals then based on the received signals the algorithm performs "configuration", which means determination of the busbar replica of the substation and an assignment of "Measuring elements" to each interconnected bus sections.

If bus sections are interconnected with each other then only one of the assigned measuring elements performs the calculation and the results are passed to all other inactive measuring elements of interconnected bus sections. Among other things, it means that the on-line displayed values will be the same for these bus sections.

The central unit performs synchronous sampling of all analog signals. These values are used by the assigned "Measuring elements" of the central unit. The "Measuring elements" perform the following tasks:

The differential current calculation is as follows:

- Summation of the sampled I_p momentary current values for the bays connected to the "Measuring element". The result is the calculated momentary value of the differential current:

$$I_{d.p} = \sum I_p$$

- Filtering the current DC component by subtracting the value sampled 10 ms before from the actual value, and the difference is divided by two. The result is the calculated momentary value of the differential current without the DC component.

$$I_{d.p1} = \frac{I_{d.p} - I_{d.p-10ms}}{2}$$

- The magnitudes of the ten last calculated values are averaged, receiving the I_d trip current. The result is the "rectified average" of the differential current. (The method is the numerical realization of the measuring principle of the Depres measuring instruments).

$$I_d = \frac{\sum_{n=1}^{10} |I_{d.pn}|}{10}$$

The biasing current calculation is as follows:

- From the absolute value of the sampled I_p momentary current values, a predetermined “Max.I_load” value, determined with parameter setting is subtracted:

$$|I_p| - \text{Max.I_load}$$

Here Max.I_load is a parameter setting, the proposed value of it is the expected maximum load current value of all bay currents but not higher than the “Base sensitivity” of the differential characteristics. The result is that in normal operation, when all bay currents are below the maximum load current, the calculated values get negative.

- Out of these differences only the values above 0 (if $(|I_p| - \text{Max.I_load}) > 0$) are summed

$$I_{s.p} = \sum (|I_p| - \text{Max.I_load})$$

The sum of these values can be positive only, if there are currents above the maximum load values, i.e. there is a fault (either external or internal of the busbar).


- Then the average of this value and that received 10 ms before is calculated:

$$I_{s.p1} = \frac{I_{s.p} + I_{s.p-10ms}}{2}$$

- The last ten calculated values stored in the memory are averaged, receiving the I_s biasing current:

$$I_s = \frac{\sum_{n=1}^{10} I_{s.pn}}{10}$$

The differential characteristics: the trip characteristic for a measuring element is shown in the Figure below.



In case of detected through fault, the slope of the characteristic is dynamically changed to 90%. When tested, the applied method results a constant 90% measured value for the slope.

Role of the subtracting the “Max.I_load” value from all current samples: in normal operation all current samples are expected to be below this setting value, which is to be the maximum possible current peak value. Consequently in normal operation the bias current is zero.

If in this state an internal fault occurs then the current samples get very fast above “Max.I_load” value. Consequently the locus of the I_d - I_s points on the plane of the differential characteristics (Figure above) is at once above the line described by the slope “k” (parameter setting “k zone”). In this case the trip command needs a few checking points only, the trip command can be fast.

In case of external fault however, the locus of the I_d - I_s points on the plane of the differential characteristics start moving in the direction of the I_s axis. If the algorithm recognizes this movement, i.e. the locus is below the line described by the slope "k" then the number of the required check points gets a high value. This extended checking period does not permit trip command generation during the time period, when the iron core of the overloaded current transformer gets saturated, and it cannot deliver proportional secondary current for the measurement.

Voltage breakdown condition: in case of current transformer circuit error, the missing current from any of the bays, the measuring element detects current difference. This could result a trip command to the bus section. To prevent this kind of operation error, the trip command is released only if in the affected bus section the voltage collapses.

To perform this supervision, the presence of the voltage is monitored with a quick voltage measuring function. The result of the supervision is considered in every millisecond. The parameters for the voltage breakdown condition are fix values.

The check zone: If any of the status signals received from the bays is wrong then the false operation based on this wrong signal could disconnect the bus section. To avoid this kind of errors the "check zone" is applied. This additional "check zone measuring element" supposes the whole busbar system as a single node. It gets all current samples from the bays except those sampled from the current transformers connecting bus sections and adds them all to get the check zone differential current. The individual measuring elements can generate a trip command only if also the "check zone measuring element" detects an internal busbar fault. The check zone operation must be enabled by parameter setting.

Saturated waveform compensation: in case of external fault, with the exception of the faulty bay, all bays deliver currents towards the busbar. The sum of these currents flows through the current transformer of the faulty bay. Consequently this current can be extremely high, which can saturate the iron core of this current transformer. The shape of this secondary current gets distorted, and the "missing" section of the wave-shape is a differential current.

To prevent unwanted operation of the busbar differential protection function for these external faults, there are several remedies. One of them is the "saturated waveform compensation". The algorithm "keeps" the detected current peak till the end of the half period, decreasing the chance for the false trip decision.

Directionality check: in case of internal fault, all bays deliver currents towards the busbar. In case of external fault however, with the exception of the faulty bay, all bays deliver currents towards the busbar, and the current of the faulty bay flows out of the busbar. When considering this basic difference, the stability of the busbar differential protection can be improved by "directionality check".

The busbar differential protection algorithm compares the sign of all current samples in a "measuring element". If during the majority of the samples one of the currents shows opposite sign, indicating opposite direction, then this fact prevents generation of the trip command.

Current transformer failure detection: if the current transformers do not deliver correct currents for the evaluation then the correct decision of the busbar differential protection is not possible.

The currents are continuously supervised also during normal operation of the system, when the currents are below the operation level of the differential protection. If in this state any of the currents is missing then a relatively high differential current is measured which is still not sufficient to operate the differential protection. The algorithm performs the current supervision based on a similar characteristic as the trip characteristic, which has a sensitive base setting and a given slope.

If the measured currents result an I_d - I_s point above this characteristic, then after a time delay the "measuring element" gets blocked.

Checking the disconnect status signals: the actual configuration of the busbar is evaluated using status signals of the disconnectors. The status of each disconnectors is characterized by dual signals: "Disconnector open" and "Disconnector closed". Only one of them can be true and one of them can be false. This function checks these status signals, and performs the decision based on parameter setting.

In normal operation when receiving faulty status signals from the disconnectors the device keeps the previous state for a time period defined by parameter setting. After this time delay the reaction of the algorithm depends on the setting of the dedicated enumerated parameter. If the setting of the "BadState Tolerate" is true (On), then the operation neglects the faulty status signal, and the last valid status is kept. In case of setting "false" (Off), the "measuring element" gets blocked.

If the status error is detected after energizing or following parameter changes, the protection remains disabled until the faulty status is corrected, and generates "Differential protection disabled" and "Breaker failure disabled" status signals as well.

Measured values: the measured and displayed values of the centralized busbar differential protection function are listed below.

For each voltage inputs, the device measures and displays the phase voltages. The Table below shows as an example the voltages of a bus section.

Measured value	Dim.	Explanation
Voltage Ch - U1	(secondary) V	Phase voltage L1, Fourier base component
Voltage Ch - U2	(secondary) V	Phase voltage L2, Fourier base component
Voltage Ch - U3	(secondary) V	Phase voltage L3, Fourier base component

For each bays the device measures and displays the phase currents. The Table below shows as an example the currents of a bay.

Measured value	Dim.	Explanation
Current Ch - I1	(secondary) A	Phase current L1, Fourier base component
Angle Ch - I1	deg*	Phase angle of the current in L1
Current Ch - I2	(secondary) A	Phase current L2, Fourier base component
Angle Ch - I2	deg*	Phase angle of the current in L2
Current Ch - I3	(secondary) A	Phase current L3, Fourier base component
Angle Ch - I3	deg*	Phase angle of the current in L3

For each bus sections the device measures and displays the differential currents and the bias currents. The Table below shows as an example the currents of a bus section.

Measured value	Dim.	Explanation
I Diff L1	(primary) A	Differential current L1, Fourier base component
I Diff L2	(primary) A	Differential current L2, Fourier base component
I Diff L3	(primary) A	Differential current L3, Fourier base component
I Bias L1	(primary) A	Bias current L1, Fourier base component
I Bias L2	(primary) A	Bias current L2, Fourier base component
I Bias L3	(primary) A	Bias current L3, Fourier base component

The breaker failure protection function:

The starting of the breaker failure protection is received on dedicated binary input channels. For operation, at least one of the phase currents of the bay must be above the level, as set an integer parameter value for each bay. Also the time delay of the function and the duration of the pulse are parameter values.

Based on the status signals of the disconnectors, the algorithm selects all bays, which are interconnected with the bay announcing breaker failure. Accordingly only the minimum number of the bays gets the trip command, the other bus-sections remain in continuous operation.

In the total description of the function, some additional features and useful advices are described in details in the Appendices.

Technical data

Function	Value	Accuracy
Current measurement		$\pm 2\%$
Current reset ratio	0.7*	
Operate time ($I_{diff} > 2 \times I_n$) ($I_{diff} > 5 \times I_n$)	Typical 20 ms <15 ms	
Reset time	60 ms	

* The reset ratio is the result of the applied special algorithm

The parameters of the centralized busbar differential protection function**Parameters of the central unit****Enumerated parameters**

Parameter name	Title	Selection range	Default
Parameter to enable the centralized busbar differential protection function:			
Busbar_BBPOper_EPar_	Operation	Off, On	Off
Parameter to enable the supervision by the "check zone"			
Busbar_CheckOper_EPar_	CheckZone Operation	Off, On	Off
Toleration of the disconnector status signal errors			
Busbar_BadTol_EPar_	BadState Tolerate	Off, On	Off

Integer parameter

Parameter name	Title	Unit	Min	Max	Step	Default
Percentage characteristic, base sensitivity						
Busbar_ZoneSens_IPar_	Base Sensitivity	A	100	10000	1	1000
Percentage characteristic, slope						
Busbar_ZoneK_IPar_	k zone	%	40	90	1	80
Checkzone percentage characteristic, base sensitivity						
Busbar_CheckSens_IPar_	CheckZone Sens.	A	100	10000	1	1000
Checkzone percentage characteristic, slope						
Busbar_CheckK_IPar_	k checkzone	%	40	80	1	50
CT error detection, base sensitivity						
Busbar_CTErrSens_IPar_	CT failure Sens.	A	50	5000	1	500
CT error detection, slope						
Busbar_CTErrK_IPar_	k CT failure	%	40	80	1	40
Maximum load current						
Busbar_Offset_IPar_	Max.I_load	A	0	10000	1	1000

Timer parameters

Parameter name	Title	Unit	Min	Max	Step	Default
Time delay for signaling bad state						
Busbar_BadDelay_TPar_	BadState Delay	msec	100	60000	1	1000
Time delay for signaling CT error						
Busbar_CTErrDelay_TPar_	CT failure Delay	msec	100	60000	1	1000

Parameters of the bus section unit

The bus section units do not need parameter setting.

Parameters of the bay unit

Boolean parameters

Parameter name	Title	Default	Explanation
Disabling the bay			
BayUnit1f_BayDisable_BPar__T1	Bay Disable	0	0 means enabling; 1 means that the current values and the status signals received from the bay are not considered (to be applied for maintenance purposes).

Enumerated parameters

Parameter name	Title	Selection range	Default
CT secondary rated current			
BayUnit1f_Nom_EPar__T1	Rated Secondary	1A, 5A	1A
Location of the CT star point for the CT-s in three lines			
BayUnit1f_Dir_EPar__T1	Star point I1-3	Line, Bus	Line

NOTE: If the bay does not include a current transformer then these parameters are missing.

Integer parameter

Parameter name	Title	Unit	Min	Max	Step	Default
CT primary rated current						
BayUnit1f_CTNom_IPar__T1	CT nominal	A	100	10000	1	1000

NOTE: If the bay does not include a current transformer then this parameter is missing.

Parameters of the sectionalizer unit

The sectionalizer units do not need parameter setting.

Parameters of the breaker failure unit

Parameters of the central unit

Enumerated parameters

Parameter name	Title	Selection range	Default
Parameter to enable the trip command distribution of the breaker failure protection function			
Busbar_BFPOper_EPar_	Intertrip Operation	Off, On	Off

Parameters of the bay unit

Enumerated parameters

Parameter name	Title	Selection range	Default
Enabling the bay to participate in the protection function			
BRF50BB_Oper_EPar__B1	Operation	Off, On	Off

Integer parameter

Parameter name	Title	Unit	Min	Max	Step	Default
Current condition for the breaker failure protection function						
BRF50BB_StCurrPh_IPar__B1	Start Ph Current	%	20	200	1	30

Timer parameters

Parameter name	Title	Unit	Min	Max	Step	Default
BRF50BB_BUDeI_TPar__B1	Backup Time Delay	msec	60	1000	1	200
BRF50BB_Pulse_TPar__B1	Pulse Duration	msec	0	60000	1	100

Binary output status signals of the centralized busbar differential protection module

The conditions of the binary input signals are defined by the user applying the graphic equation editor.

Binary output status signals of the central unit

Binary output signals	Signal title	Explanation
Busbar_Blocked_Grl__	Blocked	The busbar protection is in blocked state
Busbar_DCError_Grl__	DC Error	Disconnect status error

Binary output status signals of the bus section unit

Binary output signals	Signal title	Explanation
BusSec_TripL1_Grl__M01*	Trip L1*	L1 trip signal for the bus section
BusSec_TripL2_Grl__M01*	Trip L2*	L2 trip signal for the bus section
BusSec_TripL3_Grl__M01*	Trip L3*	L3 trip signal for the bus section
BusSec_Trip_Grl__M01	Trip	General trip command for the bus section
BusSec_BFPTrip_Grl__M01	BFP Trip	Trip command generated by the breaker failure protection function
BusSec_CTErr_Grl__M01	CT Error	Error in current measurement
BusSec_Ublock_Grl__M01	U block	The differential protection is blocked by voltage condition

* Valid in three-pole version only

Binary output status signals of the bay unit

Binary output signals	Signal title	Explanation
BayUnit1f_DCErr_Grl__T1	DC Error	Disconnect error
BayUnit1f_Trip_Grl__T1	Trip	Trip command to the circuit breaker of the bay
BayUnit_BayDisable_Grl__B1U	Bay disabled	Bay disabled

Binary output status signals of the sectionalizer unit

Binary output signals	Signal title	Explanation
SecStat_StatErr_Grl__K	Status Error	Status signal error
SecStat_SectClosed_Grl__K	Sect. Closed	Closed state of the sectionalizer

Binary output status signals of the breaker failure module

Binary output signal	Signal title	Explanation
BRF50BB_BuTr_Grl__B1	Backup Trip	Trip command for the bay, generated by the breaker failure function

Binary input status signals of the centralized busbar differential protection module

The conditions of the binary input signals are defined by the user applying the graphic equation editor.

Binary input status signals of the central unit

Binary input signals	Signal title	Explanation
Busbar_BBPBlock_GrO_	BBP Block	Blocking the busbar differential protection function
Busbar_BFPBlock_GrO_	BFP Block	Blocking the breaker failure protection function

Binary input status signals of the bus section unit

The bus section units do not have binary input status signals

Binary input status signals of the bay unit

Binary input signals	Signal title	Explanation
BayUnit_BFPTrip_GrO_	BFP Trip	Breaker failure signal from the protection of the bay. The breaker failure protection passes this signal to all bays of the interconnected bus sections, related to this particular bay
BayUnit_DC1Close_GrO_	DC1 Close	Disconnecter 1 in closed state
BayUnit_DC1Open_GrO_	DC1 Open	Disconnecter 1 in open state
BayUnit_DC2Close_GrO_	DC2 Close	Disconnecter 2 in closed state
BayUnit_DC2Open_GrO_	DC2 Open	Disconnecter 2 in open state
BayUnit_DC3Close_GrO_	DC3 Close	Disconnecter 3 in closed state
BayUnit_DC3Open_GrO_	DC3 Open	Disconnecter 3 in open state
BayUnit_DC4Close_GrO_	DC4 Close	Disconnecter 4 in closed state
BayUnit_DC4Open_GrO_	DC4 Open	Disconnecter 4 in open state
BayUnit_ForceZero_GrO_*	Force Zero*	In TRUE state of this input signal the bay unit sends zero value as the sampled current
BayUnit_BlkJect_GrO_	BlkJect	In TRUE state of this input signal the measuring element related to this bay gets in blocked state

* NOTE: In bay units without CT this parameter is missing

Binary input status signals of the sectionalizer unit

Binary input signals	Signal title	Explanation
SecStat_DC1Close_GrO_	DC1 Close	Disconnecter 1 in closed state
SecStat_DC1Open_GrO_	DC1 Open	Disconnecter 1 in open state
SecStat_DC2Close_GrO_	DC2 Close	Disconnecter 2 in closed state
SecStat_DC2Open_GrO_	DC2 Open	Disconnecter 2 in open state

Binary input status signals of the breaker failure module

Binary input signals	Signal title	Explanation
BRF50BB_BlkJect_1	Block	Blocking the breaker failure protection
BRF50BB_GenSt_GrO_1	General Start	Starting the breaker failure protection